



INSTRUCTIONS

1. CENTER WIRE GUARD OVER EXISTING PIR DETECTOR.
2. MARK AND DRILL (4) HOLES, SEE PICTORIAL FOR SIZE. LAG BOLTS- IF LAG SHIELDS AND LAG BOLTS ARE USED, MAKE SURE ANCHOR IS FLUSH WITH SURFACE. POSITION GUARD, INSERT LAG BOLT AND TIGHTEN. BOLT SHOULD BE SELECTED TO ASSURE FULL THREAD ENGAGEMENT IN ANCHOR.
3. FOR INSTALLATIONS THAT REQUIRE TAMPERPROOF FASTENERS ORDER "SUB 81" SCREWS AND PART NO. 19038 BIT.

**TYPICAL INSTALLATION OF STI
#9621, #9622 PIR WIRE GUARDS**